



WHAT TO DO IF YOU DON'T HAVE HEAT

PAPCO 6-Point Checklist:

1. Is the thermostat set to at least 5 degrees higher than your current room temperature?

If not, turn up your temperature to at least 5 degrees above your current room temperature.

2. Is the system's power switch (red EMERGENCY switch) set to the ON position?

If not, flip the power switch to the ON position.

3. Are all circuit breakers on?

It is common for a breaker to "trip" (Your circuit breaker box looks like a metal wall cabinet.) If not, reset all tripped circuit breakers. If your house has fuses, are any burned-out? If so, replace them as soon as you can.

4. Have you tried pressing and holding the RESET button for 3 seconds?

Try this ONLY ONCE. If the heat does not come on DO NOT PUSH AGAIN. This could pump too much oil into the combustion chamber. (Similar to flooding a car engine!)

5. Is the oil tank at least 1/8 full?

If not, turn off heating system immediately and call for a delivery 757-499-5977, option 1.

6. If you have a furnace (not a boiler), is your air filter clean?

A clogged air filter may cause the system to overheat and shut down.

Still no heat?

Call to schedule service: 757-499-5977 or 800-899-0747

Remember, PAPCO has the right solutions, skills and expert advice to help you!